

STEALTH

— IMMOBILISER —



OWNERS MANUAL

Before attempting to operate the Stealth Immobiliser, please ensure you have read the instructions properly

STEALTH IMMOBILISER WOULD LIKE TO THANK YOU FOR CHOOSING OUR SECURITY SYSTEM

INTRODUCTION

Stealth Immobiliser is a car security system, built for cars that use the CAN Bus System and the onboard voltage of 12V.


The STEALTH Immobiliser is a sophisticated device developed to protect the car from all known ways of theft. This digital immobiliser helps protect your car from theft, key cloning, keyless range extension, learning vehicle keys, hacking the key code from the vehicle key, and even stealing the owner's key. The device is undetectable for any theft devices and scanners since it doesn't show itself until the authorisation which can be made via personal PIN code.

The only possible way is to tow the car away because a car thief will never be able to drive away with your car. This immobiliser is a vastly improved version compared to others on the market in many ways, and in its functionality.

Elegant and advanced technical design and unique ergonomic interaction algorithms that are used in the Stealth Immobiliser allow enhancing your car with fantastic set of intuitive and useful functions.

ENVIRONMENT REFERENCE

- Old electronic devices do not belong in the bin
- If you wish to dispose this device at some point, remove all cables and send the device back to Stealth Immobiliser Limited or bring it to a collection point for old electronic devices
- You can also dispose the device together with your vehicle if scrapping. In this case device does not have to be removed
- The packaging can be recycled. Dispose the packaging in a collecting system planned for it



Environmental instructions and information on the disposal of electrical and electronic equipment including batteries (applicable to countries that have adopted a separate collection system).

If you want to dispose of this product, do not dispose of it with your normal household waste. There is a separate collection

system for used electronic equipment in accordance with legal requirements that require appropriate treatment, recovery and recycling. Contact your local authority for details on finding a recycling facility in your area. Ethical recycling and disposal help to conserve resources and prevent harmful effects on our health and the environment.

STEALTH IMMOBILISER STE-135 – USER MANUAL

1. Disarming/arming the STEALTH IMMOBILISER

Disarming – turn ON the ignition, press the previously set button combination. Single flash of the dashboard indicator will confirm disarming of the immobiliser. The time between pressing consecutive buttons must be shorter than 5 sec; in some vehicles this time must be longer than 0.4 sec.
(note: vehicles which have a ignition lock require the pin code to be entered while ignition is off)

Arming – automatically after turning the ignition OFF and opening the driver's door (2 flashes of the dashboard indicator)

Attention!

After 50 unsuccessful attempts to enter the PIN code, the device will not unlock for 30 seconds even after the correct PIN code has been entered.

The attempt is treated as unsuccessful when you make a mistake in entering the code. The device then waits for the correct sequence to be entered from the beginning.

One unsuccessful attempt is when you start entering the PIN code (by pressing one or more consecutive correct buttons) interrupted by pressing invalid button.

2. Service mode

To switch the *service mode* ON using only the PIN code, turn the ignition ON, disarm the immobiliser by entering the previously set PIN code and holding the last programmed button for 10 seconds. If you successfully managed to enable the *service mode*, the indicator on the dashboard will flash 5 times.

To switch the *service mode* OFF, just enter the PIN code holding the last button until the dashboard indicator flashes once.

Attention – switching the *service mode* ON/OFF for vehicles with a ignition lock – with the ignition OFF disarm the immobiliser by entering the previously set PIN code, switch the ignition ON and enter again the previously set PIN code holding the last programmed button for 10 seconds. If you successfully managed to enable the *service mode*, the indicator on the dashboard will flash 5 times.

If you want to switch the *service mode* off, just repeat the above procedure.

WARNING – in the *service mode* the dashboard indicator does not indicate that the *service mode* is active and the vehicle is not protected – the vehicle owner, after picking the vehicle up from servicing, should immediately switch the *service mode* OFF. During normal operation, the STEALTH IMMOBILISER indicates (by the dashboard indicator light) whether it has been armed or disarmed.

3. Changing the PIN code (changing the combination of buttons to disarm the vehicle)

Enter the previous PIN code to disarm the immobiliser. Then, follow the steps for setting the PIN code.

4. Setting the PIN code (setting the button combination)

The PIN code is a combination of any buttons available in a particular vehicle and should be given to you by your installer (supported buttons are listed on the connection diagram for the respective vehicle) .

Setting – While the ignition is ON, disarm the immobiliser by entering your PIN code and press the acceleration (gas) pedal 10 times (if the pedal is supported in a particular vehicle). Two flashes of the dashboard indicator will indicate entering into the programming mode. Press a combination of 1 to 15 supported buttons. Just after entering the combination, turn the vehicle's ignition OFF to save the new PIN code. If you do not switch the ignition OFF within 5 seconds, the new PIN code will be discarded. The indicator used to show the immobiliser's flash status will be shown to you by your installer

You must start setting new PIN code within 30 seconds from switching the ignition on. The engine must be off.

5. Switching off the auto start-stop system

Auto start-stop is a system that automatically turns off the engine, e.g., when stopping at traffic lights, and turns it on, e.g., when the clutch pedal is pressed.

To deactivate the start-stop system, switch on the ignition, then press and hold the start-stop button in the vehicle for 10 seconds. The indicator light on the dashboard will signal that memory of the start-stop system is turned off with one flash and will signal that the system is turned on with two flashes. *(NOTE: Not all vehicles are supported with this function. Please ask your installer if it is available in your particular vehicle)*

The device turns off the auto start-stop system by remembering its last selected mode.

The system will remain off until changed by the user.

6. Unlocking the immobiliser with an emergency code

Scratch cards with a unique emergency code are added to each immobiliser, allowing you to unlock the vehicle in case you do not remember your PIN code. Instructions for unlocking the immobiliser with an emergency code can be found on the scratch card attached to the device. If the card has been damaged, it is not possible to recover the emergency code. Vehicles with a ignition lock will have to contact the installer should you forget the PIN code. *(NOTE: DO NOT leave the emergency card in your vehicle at any time. Keep this safe at all times)*

CUSTOMER INSTALLATION RECORD

The STEALTH IMMOBILISER must only be installed by an approved STEALTH dealer. If you wish to see a list of approved dealers, please visit our website

Customer Details

Name:

Address:

Postcode:

Contact:

Vehicle Details

Make:

Model:

Registration:

Installer Details

Dealer ID:

Dealer Name:

Dealer Contact:

Installation Date:

Device Details

Device Name:

Device Serial:

NOTES

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

WARRANTY

All our devices are covered by a 24 month warranty when installed by an approved dealer. Below are instructions for exchanging Stealth Immobiliser devices covered under warranty. We recommend that you first attempt to exchange warranted product by contacting your installer; this is usually the fastest way to get a replacement. For Stealth Immobiliser devices that were installed in your vehicle by an authorised installer, you **MUST** contact the installer for warranty coverage, and it must be re-installed by professionals as stated in the warranty terms.

For a list of authorised dealers in your area please visit our website.

1. Your product warranty starts on the date that you purchased the product. A copy of your store receipt with the purchase date and authorised dealer's information must accompany the return of any warranted product.
2. As stated in the warranty terms that you received with your product, we may repair your defective product, or exchange it with a new or factory refurbished equivalent.
3. Your product warranty is voided if the product is damaged through negligence, misuse, or mishandling, or if any bar-coded labels or serial numbers are removed from the product.
4. Stealth Immobiliser will return the product back to you at your expense if it is not covered by the terms of the warranty.

Instructions for Returning Warranted Product for Exchange:

1. All returns and exchanges must be accompanied by an RMA number in order to be processed properly. If your product arrives without an RMA number, your warranty claim will be delayed. You must include your RMA number inside the packaging with your items (written legibly). We must receive your return package within 30 days from the date you submit your RMA request. Please retain the RMA number for your records.

To request an RMA form please send us a email on: enquiries@stealthimmobiliser.com

2. You are responsible for return delivery costs. You may use your preferred courier. We recommend that you use a traceable method of delivery. If your shipment is lost for any reason and you do not have proof of delivery, you will not receive a replacement.
3. Pack your return carefully. The package you return to us must include the device, emergency card and the warranty book. In addition, you must also include a copy of your original proof of purchase. Please note you will be responsible for the cost of any missing items.
4. Please allow 2 to 3 weeks for your exchange to be processed.

To register your devices warranty please visit

www.stealthimmobiliser.com/warrantyform



Stealth Immobiliser Limited
United Kingdom
enquiries@stealthimmobiliser.com
www.stealthimmobiliser.com

